

WARNING

FOR YOUR SAFETY, Outdoor Use Only, Before using your outdoor fire pit, make sure you have read and understand all of the following information provided. Failure to follow these instructions can cause death, serious injury or property damage.



- (1) This fire pit is for outdoor use only. And shall NOT be used indoors or in any enclosed building.
- (2) Do NOT leave a lit outdoor fire pit unattended, especially around children and pets.
- (3) This outdoor fire pit shall NOT be operated by minors.
- (4) This outdoor fire pit is NOT to be used in or on boats or recreational vehicles.
- (5) Always use in accordance with all applicable local, state and national codes. Contact your local fire department for details on outdoor burning.
- (6) When using this outdoor fire pit, exercise the same precautions you would with any open fire.
- (7) The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to properly assemble or safely operate this outdoor fire pit.
- (8) This outdoor fire pit is for use with dry, seasoned hardwood. It will burn hotter, more completely and create less smoke.
- (9) Do NOT burn, trash, leaves, paper, cardboard, plywood, painted or stained or pressure treated wood. Avoid using softwoods such as pine or cedar that can throw sparks.
- (10) Do NOT store or use gasoline or other flammable vapors or liquids in the vicinity of this outdoor fire pit.
- (11) Do NOT store or use an LP gas cylinder within 20 feet of this outdoor fire pit while it is in operation.
- (12) Do NOT use this outdoor fire pit near automobiles, trucks, vans or recreational vehicles.
- (13) Do NOT use in an explosive atmosphere. Keep outdoor fire pit area clear and free from combustible materials, gasoline and other flammable liquids.
- (14) Do NOT use this outdoor fire pit under any overhead or near any unprotected combustible constructions. Avoid using near or under overhanging trees and shrubs.
- (15) Always use this outdoor fire pit on a hard, level non-combustible surface such as concrete, rock or stone. An asphalt or blacktop surface may not be acceptable for this purpose. Do NOT use on wooden or composite decks.
- (16) Always empty this outdoor fire pit before each use.
- (17) Do NOT remove ashes or coals until they are completely and fully extinguished.
- (18) Use heat-resistant gloves or hot pads when contacting handles.
- (19) All surfaces of this outdoor fire pit are hot when in operation. To avoid burns, do NOT touch fire pit until it has completely cooled unless you are wearing protective gear (Potholders, gloves, BBQ mittens, hot pads & etc.). Never touch ashes or coals to see if they are hot.
- (20) Do NOT use gasoline, kerosene, diesel fuel, lighter fluid or alcohol to light or relight fires.
- (21) Do NOT use in windy conditions.
- (22) Do NOT place hot fire pit tools onto combustible surfaces such as grass, wooden deck or Furniture.
- (23) Avoid breathing smoke from the fire and avoid getting it into your eyes.
- (24) Deaths, serious injury or damage to property may occur if the above is not followed exactly.

Lighting

- (1) Place a layer of dry kindling or a natural fire starter onto the center of the fire pit.
- (2) Place above that a layer of dry seasoned hardwood that is cut to lengths no more than 3/4 the diameter of the fire pit.
- (3) Use a match to light kindling or fire starter.

Tending the Fire

- Always wear protective gloves or a pot holder when tending fire.
Wait until glowing coals have developed before adding any additional wood.
Do NOT add gasoline, kerosene, diesel fuel, Lighter fluid or alcohol to relight or enhance an existing fire.
Use a long handled fire poker tool, shift coals and logs to allow additional airflow.
3. If additional wood is required, place wood on top of coals. Be careful not to shift ashes.

Extinguishing

1. Always allow fire to burn itself out.
2. Do NOT use water to extinguish as this is dangerous and can cause damage to this outdoor fire pit.

Cleaning and Storage

Outdoor fire pit should be cleaned on a regular basis to promote safer experiences and longer product life.
Do NOT move or store this outdoor fire pit until the fire is COMPLETELY out.
Once the fire is out, coals are cold and outdoor fire pit is cool to the touch, remove ashes and properly dispose.

Note

If you do not use a cover to store this outdoor fire pit put in a dry location to maximize product life.

Manufactured in America By
Pitstop outdoors LLC